

**LOCK CYLINDER INSTALLATION
FOR 400 SERIES KEY TRAP
SCHLAGE MODULAR CYLINDER
SPECIFY FOR USE WITH 1-1/8" OR 1-1/4" CYLINDER.**

Thread Schlage modular cylinders into the key trap as shown in the picture.



Secure cylinders with two set screws. The cylinder should be flush or a little above the inside of the trap. It may be necessary to run a 8-32 tap down the side of the cylinder / key trap slot for the screw to thread in smoothly.



With the cylinders secured with the cylinder set screws, remove the cams from the back of the cylinders. **It is a good idea to do this step with the keys removed from the cylinder.**



Major
MANUFACTURING, INC.

1825 Via Burton, Anaheim, CA, 92806

714-772-5202 / Fax 714-772-2302 / Email / mail@majormfg.com / web www.majormfg.com

The timing links used are shown at the right. One is marked 1/4 1/2 and 3/4. It is used for a 1-1/4" cylinder. The other is marked 1/8, 3/8, and 5/8. Use it for 1-1/8" cylinders. Install the correct link on one of the mortise cylinders. Put a key into the cylinder (the one with the cam attached) and turn until you can line up the second cam on the opposite cylinder and attach the cam.

The key trap is now ready to use.



Completed installation of the Schlage Modular cylinders. Link will allow only one key to be removed at a time. Returning one key and turning will allow removal of the other.

Major
MANUFACTURING, INC.

1825 Via Burton, Anaheim, CA, 92806

714-772-5202 / Fax 714-772-2302 / Email / mail@majormfg.com / web www.majormfg.com